PIPE LUBRICANT

For Cherry Pipes pipe jointing



Product Overview

Cherry Pipes Pipe Lubricant is used to help reduce the jointing force required when installing pipes. Cherry Pipes strongly advises using this product only when joining Cherry Pipes pipes and fittings. The product has been tested for use with our pipe systems to support suitable jointing and installation.

Key Features

• Helps reduce jointing forces during installation	• For use when joining Cherry Pipes products
• Supports pipe jointing and installation	• Available in selected package sizes

Available Packaging

Package	Container	Use
500 ml	Tube	Cherry Pipes pipe jointing
1 kg	Can	Cherry Pipes pipe jointing
3 kg	Pail	Cherry Pipes pipe jointing

Installation

1.	Clean the socket and spigot.
2.	Apply lubricant to the socket and spigot.
3.	Push the pipes together.

Storage

Store at +5°C to +30°C, as stated on the Cherry Pipes lubricant label.

Cherry Pipes Limited
12 Derryhirk Road, Dungannon, BT71 6NH
Tel: 028 3885 3900
sales@cherrypipes.com
www.cherrypipes.com

Note: This is a product datasheet based on the information provided by Cherry Pipes. It is not a Safety Data Sheet (SDS). Refer to the manufacturer's current SDS for detailed safety, handling and regulatory information.